

# IzoT Markup Language (IML)

This section consists of the following:

- [IzoT Markup Language \(IML\) Overview](#)
- [Specifying IML Device Options](#)
- [Specifying the Program ID](#)
- [Accessing the IzoT Device Interface](#)
- [Implementing a Block](#)
- [Implementing a Device Datapoint](#)
- [Handling a Datapoint Event](#)
- [Implementing a Device Property](#)
- [Handling a Device Event](#)
- [Using a Bitfield Data Type](#)
- [Using an Enumeration Data Type](#)
- [Using a Union Data Type](#)
- [Communicating Using Application Messages](#)
- [Defining a User Profile or Data Type](#)
- [IML Syntax Summary](#)
- [IML Errors and Warnings](#)