

Getting More Information

Python-based reference documentation for the IzoT SDK stacks is embedded in the Python packages. To access this documentation, open a Linux shell and, at the prompt, enter **pydoc3 izot**. This will give you a list of IzoT top-level packages. Still in the Linux shell, enter the name of any of the listed packages shown, preceded by **izot**. (e.g., **pydoc3 izot.device**), and you will receive a document supporting that package. Alternatively, click the **IzoT SDK Python Docs** button, or browse to **/pydocs/**, on the home page of any IzoT device.

Reference documentation for the IzoT SDK Device Stack EX is also available. To access this documentation, click the **IzoT Device Stack EX Docs** button, or browse to **/docs/DeviceStack**, on the home page of any IzoT device.

Reference documentation for the IzoT REST API provided by the IzoT Server is available by clicking the Browsable **IzoT REST API** button on the home page of a device running the IzoT Server.

See the [Adesto website](#) for more information on the IzoT Platform.